OAS-DSP NU-2000 농도측정모듈

2021. 04. 12



1. Major parts Confidential


	78	사양		
	구분	UV	MIR	
Light source	Peak Wavelength	275±5nm	2250(+40/-30)nm	
	Bandwidth	12nm	200nm	
	Optical power	1~2mW @100mA lop	0.9~1.3mW @200mA qCW 25~30mW @1A Pulse	
	Emitting area	(~0.8mmX0.8mm)	300umX300um	
	Viewing angle	>15° @20% lpeak	3~4°@FWHM	
	Life time	8000hrs typ. @20mA 3000hrs typ. @100mA	80000hrs	
	Part name	Optan-275J-BL(Optan)	LED22-R (Roithner)	
Detector	Active area	2.4mmX2.4mm	Ф1.0mm	
	Responsivity	0.38A/W @275nm	1.3A/W @2300nm	
	Part name	S12698-01(Hamamatsu)	G12183-010K(Hamamatsu)	




2. Design factor


Confidential

- 약액의 leak 방지
 - Sealing 구조의 상호검증, 데이터 공유
 - PTFE 소재의 casing 적용
 - A/V 구조 상 일부 오픈
- Life-time 제고 방안
 - 방열 구조 적용
 - UV : non-active cooling
 - MIR: active cooling
- 수리용이성 확보
 - 기능별 module화 설계
 - LED, PD의 교체 방안
 - 테스트 가능한 구조 적용
- Noise 제거 방안
 - Baffle 구조의 적용
 - Various aperture size 적용
- 내화학성 확보
 - PTFE
 - PEEK 수지 볼트



- Monitoring detector signal을 활용
- 온도에 따른 출력 및 spectrum 변화
 - MIR의 경우 spectrum 변화가 심함 : 온도 유지 장치 필요(Peltier 소자등)








3. Optical layout

Confidential

UV/MIR module






4. Optical aperture

Confidential

UV module






4. Optical aperture

Confidential

MIR module






5. configuration

Confidential

UV module





5. configuration


Confidential


Out UV module Flow cell RTD sensor PD board LED board Air cylinder & speed valve Heatsink plate /w peltier module MPD board



6. Dimensions Confidential

UV module










6. Dimensions Confidential

MIR module









Appendix. air-cylinder specification

Confidential


• SMC社 CJP2B6-20D


복동형 air cylinder

- Stroke: 20mm

- A: 33+20=53mm

Configuration







치수표		단위 : mm	
튜브내경	Α	В	С
4	29+스트로크 (34+스트로크)	14	14.5
6	33+스트로크 (38+스트로크)	14	16.5
10	39.5+스트로크 (44.5+스트로크)	15	19
16	43.5+스트로크 (48.5+스트로크)	20	24.5

※()안은 자석내장형의 치수



Confidential








Appendix. A/V material

Confidential

- Reference plate
 - UV module : EdmundOptics #45-809
 - 12.5mm Dia. UV AR coated
 - Material: Fused silica
 - Wavelength range: 250 450nm
 - Coating spec. : R<0.75%@250-450nm(avg)
 - Index of refraction: 1.458



TECHSPEC® 1λ UV Fused Silica Windows

- MIR module : EdmundOptics #15-991
 - 12.5mm Dia. BBAR AR coated
 - Material : Sapphire
 - Wavelength range: 1650-3000nm
 - Coating spec. : R<1%@1650-3000nm(avg)
 - Index of refraction: 1.77



TECHSPEC® AR Coated Sapphire
Windows

